

# MULTIPURE® | O-RINGS

1. Remove the showerhead or shower wand hose from the outlet (male) thread of the Aquashower housing
2. Remove the Aquashower by unthreading it from the shower arm or supply pipe
3. Open the Aquashower body by unscrewing it
4. Remove the Outlet Cap O-ring (A). This o-ring is round in profile and about 2.5" in diameter – it is slightly thicker than the Cosmetic Body O-ring (B)
5. Replace the Outlet Cap O-ring (A) with the new Outlet Cap O-ring in this package. Lubricate the o-ring with a small amount of silicone grease. Be sure to seat the o-ring in the recessed groove in the housing.
6. Remove the inlet body quad o-ring (C). This o-ring is a flat gasket, about 1" in diameter.
7. Replace the inlet body quad o-ring (C) with the new Inlet Body Quad O-ring in this package. Lubricate the o-ring with a small amount of silicone grease. Be sure to seat this gasket in the recessed groove in the housing.
8. Remove the Cosmetic Body O-Ring (B) from the threads of the shower filter housing.
9. Replace the Cosmetic Body O-Ring (B) with the new Cosmetic Body O-Ring in this package. As this o-ring is only cosmetic in nature, it does not need to be lubricated.
10. Insert a new replacement Aquashower filter cartridge (part # AQSf), reassemble the housing by threading it together (hand-tighten) and re-install the Aquashower in your shower.

