

WARRANTY

The manufacturer warrants the product to be free from defects in materials and workmanship when installed, operated, and maintained in the manner instructed in this document. It is warranted for a period of one year from the date of purchase. The manufacturer will repair or replace this prefilter that fails to perform due to faulty materials or workmanship. Items not covered under the warranty include: damage due to misuse, improper maintenance, improper installation, excessive water pressure or temperature, freezing, or general misapplication of the product's use and purpose. There are no warranties, expressed or implied, other than those stated herein. Multipure is not liable in any way for any damages arising from the misuse or misapplication of this product. To make claims under this warranty, please contact your dealer.



7251 Cathedral Rock Dr.,
Las Vegas, NV 89128
702.360.8880 • 800.622.9206

www.multipure.com

F528-RS / 1219



AQUAGROW
Washable Prefilter

INSTRUCTION GUIDE

- Thank you for your purchase of Multipure's Aquagrow Prefilter.
- The Aquagrow Prefilter is designed to treat high levels of particulate matter and sediment in the water prior to entering the Aquagrow dechlorinator, extending its effective filtration media life. The Aquagrow Prefilter is washable and reusable.
- CAUTION: The Aquagrow Prefilter uses a special 15-micron fine mesh double screen. Handle with extreme care so as to avoid damage to this screen.

INSTALLATION

1. Attach one end of the Prefilter Hose Saver to the water supply faucet.
2. Attach the other end of the Prefilter Hose Saver to the Aquagrow Prefilter thread labeled "inlet"
3. Attach one end of the Aquagrow Hose Saver to the Aquagrow Prefilter thread labeled "outlet"
4. Attach the other end of the Aquagrow Hose Saver to the Aquagrow.
5. Attach the garden hose to the other end of the Aquagrow.

MAINTENANCE

Sediment and other particulate matter collected by the Prefilter is deposited on the inside surface of the metal filter screen inside the clear plastic bowl of the Prefilter. Periodic cleaning of the Prefilter will extend the optimal performance and filter life of the Aquagrow.

1. Unscrew the clear plastic bowl on the Prefilter.
2. Remove the metal filter screen from the clear plastic bowl.
3. While rinsing the filter screen under running water, scrub the screen with a small brush (NOT a toothbrush) or a finger.

NOTE: Be careful not to bend or damage the screen.

4. Place the cleaned filter screen back in the clear plastic bowl, and reconnect the clear plastic bowl and filter screen to the Prefilter.

